

Hardware Installation

1. Wait until the restart of your computer after installation of the CB-2 software is completed.
2. Connect the CB-2 box to a free USB port of your computer using the USB cable provided
3. Windows will display the balloon “New hardware found”
4. The following messages are displayed:
CB-2
USB Serial Converter A
CB-2
USB Serial Converter B
CB-2
USB Serial Converter C
CB-2
USB Serial Converter D
USB Serial Port
USB Serial Port
USB Serial Port
USB Serial Port
5. The last message will be:
Your new hardware is installed and ready to use.
6. The installation is completed

Note: it is possible that the balloon isn't displayed and that Windows installs the drivers quietly. There will be no user interaction.

Configuration

1. Start CB-2 Utility
2. CB-2 Utility will scan all com ports of your computer for a CB-2 box
3. The configuration dialog of CB-2 Utility will be displayed. An indication will be given for USB Com ports that have a CB-2 box connected.
4. Click on the com port that has a CB-2 box connected. The description of this port is CB-2 A.
5. If you forgot to turn on the CB-2 box, turn it on and press **Refresh**
6. If you have multiple printers configured on your computer and you don't always want to print on the default printer, check “Show Print Dialog”.
7. Click **OK** to confirm your settings
8. Configuration is now completed and the CB-2 main dialog will be displayed

Note: On some computers a restart is required after installation of the USB drivers.

Software updates: <http://www.cb-2.nl>

The registration code for RKC1000E (garment shaping program) is the serial number of the CB-2 box. You find the serial number on the bottom of the CB-2 box. The format of the serial number is CB2-yy-mm-nnnnn.

Quickstart installation instructions

Parts list Control Box 2

1. CB-2 box
2. USB cable
3. Power Supply + power lead
4. CD or stick with CB-2 Utility, Pattern Explorer and USB drivers
5. Velcro
6. This leaflet.

Software Installation

NOTE: INSTALL THE SOFTWARE BEFORE CONNECTING THE CB-2 BOX TO THE COMPUTER

1. Insert the CB-2 installation CD in the Cd rom drive
2. The CB-2 installation program will start automatically
3. If autorun is not enabled on your computer, look for the Cd rom and double click on Autoplay.exe in the root of the CD
4. Click on **Pattern Explorer (English)**
5. Follow the on screen instructions; the InstallShield installation wizard will guide you through the process
6. Click on **CB-2 Software (English)**
7. Follow the on screen instructions; the InstallShield installation wizard will guide you through the process
8. Before clicking **Finish**, check that the installation of the USB drivers is completed. Move the installation dialog so you can see whether another program is covered by the installation dialog.
9. Restart your computer by clicking **Yes** on the restart dialog.

Note: It is recommended to install CB-2 Utility in the suggested folder.